

Headlight Switch E-Bike

Function Switch (S1)

For E1 / E2 / E4 / E6

Part No. : 2B4020101



Switch Button E-Bike

Power Switch (S2)

For E3

Part No. : 2B4020102



Electric Bike Switch (S3)

Part No. : 2B4020103



Electric Bike Switch (S4)

Part No. : 2B4020104



Multifunction Switch (S5)

Part No. : 2B4020105




On & Off Switch 12V

(S6-Blue)


Part No. : 2B4020106



3-segment Switch (S7)



On & Off Switch (S8)



Multifunction Switch(S9)



Multifunction Switch (S10)



Multifunction Switch (S11)



Multifunction Switch (S12)



Multifunction Switch (S13)



E-MARK Electric Bike Horn

Ø2.6 inch

105 dB



E4